



Guide to WATERING GRASS

1

Identify your sprinkler type



Spray: steady spray of water over area



Rotor: single stream rotates over area



Multi-Stream Rotor: multiple streams rotate over area

2

Set 'Start Times' and 'Run Time'

All sprinkler types
Three (3) start times
One (1) hour apart



Spray sprinklers
6-minute run
(18 minutes total)



Rotor and Multi-Stream Rotor sprinklers
25-minute run
(75 minutes total)

Tip: Only water when the sun is down to prevent evaporative loss.

3

Adjust your schedule

Follow this watering frequency
(Days between watering)

Season	Bermuda Summer grass	Rye Winter grass
Winter	once every 15 days	once every 7 days
Spring	once every 4 days	once every 3 days
Summer	once every 3 days	none
Fall	once every 6 days	once every 3 days

Tip: Don't set it and forget it. Sign up for free monthly watering reminders by texting: WHENTOWATER to 33222.

4

Fine tune for water efficiency

Push a screwdriver into the soil and adjust run time based on depth.

Less than 6": Increase run time
More than 10": Decrease run time
Between 6-10": You found the **perfect** run time!

Tip: Wait one hour after last watering to check depth.

